



STEPS TO FOLLOW FOR THE PROFESSIONAL CLOSING KIT

CONTENTS OF KIT:

- 1 x 1 KG **ALKA-PLUS**
- 1 x 500 ML **CLEARWATER ALGAE 40**
- 1 x 250 ML **CLARIFIER PLUS**

****The following directions for use supersede the ones on the individual product inside the kit.**

DIRECTIONS FOR USE:

Application method

- **CLEARWATER ALGAE 40** : Pour product directly onto the surface of water while walking all around the pool.
- **ALKA-PLUS** Sprinkle product directly onto the surface of water while walking all around the pool. Avoid adding product in one spot to ensure it dissolves properly.
- **CLARIFIER PLUS**: Pour product directly onto the surface of water while walking all around the pool.

For optimal results, always follow these steps:

1. Remove the solar cover.
2. Clean the water line and pool surfaces.
3. Adjust the pH of water to between 7.2 and 7.8 according to the instructions on the product used (pH balancing products sold separately).
4. Remove the ladder, diving board, skimmer basket and skimmer door. Do not remove the screws from the plates.
5. Lower the level of the pool water so that it is 12 to 18 inches below the water return.
6. Blow or draw all the air from the water pipes with three-way valve handle in position 1 to close the skimmer. This position should be at the top towards the skimmer. The use of a wet/dry vacuum is recommended for in-ground pools or underground pipes. Next, block the skimmer as recommended by your pool retailer and cap the return jet with the appropriate threaded or expansion plug.
7. Add the entire contents of **CLEARWATER ALGAE 40** according to the application method. Wait 30 minutes.
8. Add the entire contents of **CLARIFIER PLUS** according to the application method. Wait 30 minutes.
9. Add the entire contents of **ALKA-PLUS** according to the application method.
10. Add the undiluted antifreeze to the water pipes via the skimmer. Continue adding until the coloured antifreeze appears at the bottom drain. If using antifreeze for a water heater, pour it in the water inlet. Your pipes and equipment are now ready for the winter. Be sure to treat all connection pipes, jets and equipment.
11. Install the winter cover.